### WARRANTY

We strive to offer high-quality products, and we also try our best to satisfy each and every customer that orders from us with product or service as needed. We provide 30 days warranty starting from the time you receive the item. Each customer must provide a record of their order such as the order number, or item receipt for any items that are out of the warranty period you may also still receive replacement parts by purchasing them with our company if they are available.

Are you having difficulty
with assembly? Missing parts?
Please send email with your order No

customerservice@hulalahome.com

For return, Please check the return policy with the retailer or MarketPlace you bought from.

Appreciated your purchasing from us. Pop up your life by our furniture piece!





#### NOTE:


This brochure contains IMPORTANT safty info. Please read and keep for future reference.

## MAINTAINANCE AND WARNING


- Keep furniture away from heat.
- Do not clean furniture with harsh cleansers or polish. Do not use detergents, Solvents, abrasives, spray packs or leather cleaner. Use non-color mild soap with warm water clean spills(Mix 1:10 soap to water)
- Do not place furniture under direct sunlight, material will possibly fade over time.
- Do not use on site dry Cleaning machine.
- Children should not climb or jump on the furniture.
- Do not write on furniture without a padded barrier to protect the surface.
- Not for commercial use, For residential use only.



## PARTS LIST



# HARDWARE LIST





## SPARE



Be sure to check all packing material carefully for small parts.which may have come loose inside the carton during shipment.


### STEP1






STEP1:Use bolt ①, allen key③ to Attach the metal bracket I to inside of armrest (A/B). Make sure the holes aligned properly then fasten all bolts to secure.

#### STEP2




STEP2: With help of adult partner, carefully align the male and female metal bracket then push the backrest(C) all the way down in order to secure it to inside of armrest A/B.

### STEP3




STEP3:Use bolt①, allen key③, bracket L to connect armrest A/B with backrest C. Please don't fasten any bolt until end of step 5.

#### STEP4




STEP4:Use bolt ① to connect metal bar H with armrest A/B, make sure the metal bar set leveled .Please don't fasten any bolt until end of step5.

## STEP5




STEP5:Use bolt ①, allen key ③, bracket K to connect armrest A/B with front rail G, make sure armrest A/B, backrest C and front rail G aligned then fasten all bolts to secure.




STEP6:Use bolt①, allen key③ to attach legs I to bottom of the armrest A/B, fasten bolts to secure.


### STEP7



STEP7:Use philips head screwdriver ③ and screw ② to attach seat panel D to front rail G and backrest C, fasten to secure.

## STEP8 STEP9





STEP8:Put the seat cushion F on the seat panel D. Put the barkrest cushion E on top of the seat cushion F.

